

# Instructions for mounting BODY BIKE Performance console

## Box contents:

1 Performance console  
1 console bracket

1 lock fitting  
2 stainless steel screws  
M5x10 A2

3 black screws M5x10  
1 Allen key  
3 AAA batteries 1,5 V

1. Place the bottom of the bracket as shown on the figure (the dotted part). Press the bottom of the bracket in place. It may be necessary to push to fit it. Push back on the bottle holder to counter the pressure.
2. Nudge the top of the bracket in position right above the tip of the bottle holder. Carefully press down until it clicks. Again push back on the bottle holder to counter the pressure.
3. Place the lock fitting under the bottleholder and screw the two stainless steel screws into the fitting with the Allen key.
4. Place the console on the bracket - make sure that the batteries are inserted. Screw the three black screws up into the bracket and console using the Allen key. Keep a hand on the console until the first screw is in to avoid it falling off.

